

CDX-GT06/CXS-GT06HP

SERVICE MANUAL

US Model

Ver. 1.0 2006.07



- CXS-GT06HP is composed of CDX-GT06, 2 way speaker, 3 way speaker.

(Photo: CDX-GT06)

- The tuner and CD sections have no adjustments.

AUDIO POWER SPECIFICATIONS

POWER OUTPUT AND TOTAL HARMONIC DISTORTION
22 watts per channel minimum continuous average power into 4 ohms, 4 channels driven from 20 Hz to 20 kHz with no more than 5% total harmonic distortion.

Model Name Using Similar Mechanism	CDX-GT10W/GT100
CD Drive Mechanism Type	MG-611XE-186/C
Optical Pick-up Name	KSS1000E

SPECIFICATIONS

CD Player section

Signal-to-noise ratio: 120 dB
Frequency response: 10 – 20,000 Hz
Wow and flutter: Below measurable limit

Tuner section

FM

Tuning range: 87.5 – 107.9 MHz
Antenna terminal: External antenna connector
Intermediate frequency: 10.7 MHz/450 kHz
Usable sensitivity: 9 dBf
Selectivity: 75 dB at 400 kHz
Signal-to-noise ratio: 67 dB (stereo), 69 dB (mono)
Harmonic distortion at 1 kHz: 0.5 % (stereo), 0.3 % (mono)
Separation: 35 dB at 1 kHz
Frequency response: 30 – 15,000 Hz

AM

Tuning range: 530 – 1,710 kHz
Antenna terminal: External antenna connector
Intermediate frequency: 10.7 MHz/450 kHz
Sensitivity: 30 μ V

Power amplifier section

Outputs: Speaker outputs (sure seal connectors)
Speaker impedance: 4 – 8 ohms
Maximum power output: 45 W $\times$ 4 (at 4 ohms)

General

Outputs: Audio outputs terminal (sub/rear switchable)
Power antenna relay control terminal
Power amplifier control terminal
Inputs: Antenna input terminal
AUX input jack (stereo mini jack)
Tone controls: Low: $\pm$ 10 dB at 60 Hz (XPL0D)
Mid: $\pm$ 10 dB at 1 kHz (XPL0D)
High: $\pm$ 10 dB at 10 kHz (XPL0D)
Power requirements: 12 V DC car battery (negative ground)
Dimensions: Approx. 178 $\times$ 50 $\times$ 179 mm
(7 1/8 $\times$ 2 $\times$ 7 1/8 in) (w/h/d)
Mounting dimensions: Approx. 182 $\times$ 53 $\times$ 161 mm
(7 1/4 $\times$ 2 1/8 $\times$ 6 3/8 in) (w/h/d)
Mass: Approx. 1.2 kg (2 lb 11 oz)
Supplied accessories: Parts for installation and connections (1 set)

– Continued on next page –

FM/AM COMPACT DISC PLAYER

9-887-357-01
2006G04-1
© 2006.07

Sony Corporation
eVehicle Division
Published by Sony Techno Create Corporation

SONY®

CDX-GT06/CXS-GT06HP

6 × 9 Speaker (3-way Speaker)

Speaker	Coaxial 3-way: Woofer 16 × 24 cm (6 3/8 × 9 1/2 in), cone type Midrange 5.5 cm (2 1/4 in), cone type Tweeter 1.4 cm (9/16 in), balanced dome type
Peak power	300 W
Rated power	60 W
Impedance	4 Ω
Sensitivity	93 dB/W/m
Frequency response	27 – 30,000 Hz
Mass	Approx. 1,150 g (2 lb 9 oz) per speaker
Supplied accessory	Parts for installation

6 1/2 Speaker (2-way Speaker)


Speaker	Coaxial 2-way: Woofer 16 cm (6 3/8 in), HOP, cone type Tweeter 4 cm (1 5/8 in), Al, cone type
Peak power	190 W
Rated power	40 W
Impedance	4 Ω
Sensitivity	90 dB/W/m
Frequency response	35 – 22,000 Hz
Mass	Approx. 560 g (1 lb 4 oz) per speaker
Supplied accessory	Parts for installation

Design and specifications are subject to change without notice.


Dimensions Dimensiones

Unit: mm (in)
Unidad: mm

6 × 9 Speaker Altavoz de 6 × 9



6 1/2 Speaker Altavoz de 6 1/2



SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK $\triangle$ OR DOTTED LINE WITH MARK $\triangle$ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

SERVICE NOTES

CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

NOTES ON HANDLING THE OPTICAL PICK-UP BLOCK OR BASE UNIT

The laser diode in the optical pick-up block may suffer electrostatic breakdown because of the potential difference generated by the charged electrostatic load, etc. on clothing and the human body. During repair, pay attention to electrostatic breakdown and also use the procedure in the printed matter which is included in the repair parts.

The flexible board is easily damaged and should be handled with care.

NOTES ON LASER DIODE EMISSION CHECK


The laser beam on this model is concentrated so as to be focused on the disc reflective surface by the objective lens in the optical pick-up block. Therefore, when checking the laser diode emission, observe from more than 30 cm away from the objective lens.

Notes on Chip Component Replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.

If the optical pick-up block is defective, please replace the whole optical pick-up block.


Never turn the semi-fixed resistor located at the side of optical pick-up block.



EXTENSION CABLE AND SERVICE POSITION

When repairing or servicing this set, connect the jig (extension cable) as shown below.

- Connect the MAIN board (CNP301) and the SERVO board (CN1) with the extension cable (Part No. J-2502-076-1).



TEST DISCS

Please use the following test discs for the check on the voltage and the waveforms of the CD section.

YDES-18 (Part No. 3-702-101-01)

PATD-012 (Part No. 4-225-203-01)

Notes on CD-DA/CD-R/CD-RW

- CD playback:

You can play CD-DA and CD-R/CD-RW for audio use.



● UNLEADED SOLDER

Boards requiring use of unleaded solder are printed with the lead-free mark (LF) indicating the solder contains no lead.

(Caution: Some printed circuit boards may not come printed with the lead free mark due to their particular size.)



: LEAD FREE MARK

Unleaded solder has the following characteristics.

- Unleaded solder melts at a temperature about 40°C higher than ordinary solder.

Ordinary soldering irons can be used but the iron tip has to be applied to the solder joint for a slightly longer time.

Soldering irons using a temperature regulator should be set to about 350°C.

Caution: The printed pattern (copper foil) may peel away if the heated tip is applied for too long, so be careful!

- Strong viscosity

Unleaded solder is more viscous (sticky, less prone to flow) than ordinary solder so use caution not to let solder bridges occur such as on IC pins, etc.

- Usable with ordinary solder

It is best to use only unleaded solder but unleaded solder may also be added to ordinary solder.

TABLE OF CONTENTS


1. GENERAL	
Location of Controls and Basic Operations	5
Connections	5
2. DISASSEMBLY	
2-1. Sub Panel Assy	8
2-2. CD Mechanism Block	8
2-3. Main Board	9
2-4. Chassis (T) Sub Assy	9
2-5. Roller Arm Assy	10
2-6. Chassis (OP) Assy	10
2-7. Optical Pick-up	11
2-8. SL Motor Assy (M902)	11
2-9. LE Motor Assy (M903)	12
2-10. Servo Board	12
3. DIAGRAMS	
3-1. Block Diagram –CD Section–	13
3-2. Block Diagram –Main Section–	14
3-3. Block Diagram –Display Section–	15
3-4. Circuit Boards Location	15
3-5. Printed Wiring Boards –CD Mechanism Section–	16
3-6. Schematic Diagram –CD Mechanism Section–	17
3-7. Printed Wiring Board –Main Section–	18
3-8. Schematic Diagram –Main Section (1/3)–	19
3-9. Schematic Diagram –Main Section (2/3)–	20
3-10. Schematic Diagram –Main Section (3/3)–	21
3-11. Printed Wiring Boards –Key Section–	22
3-12. Schematic Diagram –Key Section–	23
4. EXPLODED VIEWS	
4-1. Main Section	31
4-2. Front Panel Section	32
4-3. CD Mechanism Section (1) (MG-611XE-186//C)	33
4-4. CD Mechanism Section (2) (MG-611XE-186//C)	34
4-5. CD Mechanism Section (3) (MG-611XE-186//C)	35
4-6. CD Mechanism Section (4) (MG-611XE-186//C)	36
5. ELECTRICAL PARTS LIST	37

SECTION 1 GENERAL

This section is extracted from instruction manual.

Location of controls and basic operations

Main unit




- | | |
|--|--|
| <p>1 OFF button
To power off; stop the source.</p> <p>2 Volume control dial/select button
To adjust volume (rotate); select setup items (press and rotate).</p> <p>3 EQ3 (equalizer) button
To select an equalizer type (XPLOD, VOCAL, CLUB, JAZZ, NEW AGE, ROCK, CUSTOM or OFF).</p> <p>4 Disc slot
To insert the disc (label side up), playback starts.</p> <p>5 Display window</p> <p>6 ▲ (eject) button
To eject the disc.</p> <p>7 DSPL (display)/DIM (dimmer) button
To change display items (press); change the display brightness (press and hold).</p> <p>8 🖱 (front panel release) button</p> <p>9 SEEK +/- buttons
CD:
To skip tracks (press); skip tracks continuously (press, then press again within about 1 second and hold); reverse/fast-forward a track (press and hold).
Radio:
To tune in stations automatically (press); find a station manually (press and hold).</p> | <p>10 SOURCE button
To power on; change the source (Radio/CD/AUX).</p> <p>11 BTM button
To start the BTM function (press and hold).</p> <p>12 MODE button
To select the radio band (FM/AM).</p> <p>13 RESET button (located behind the front panel)</p> <p>14 Number buttons
CD:
③: REP
To play the current track repeatedly.
④: SHUF
To play the tracks in random order.
Radio:
To receive stored stations (press); store stations (press and hold).</p> <p>15 SENS button
To improve weak reception: LOCAL/MONO.</p> <p>16 AUX input jack
To connect a portable audio device.</p> |
|--|--|


• CONNECTIONS

2

A



B



* AUDIO OUT SUB/REAR

Connection

Connection example 2

Notes (2-B)


- Be sure to connect the ground lead before connecting the amplifier.
- The alarm will only sound if the built-in amplifier is used.

Conexión

Ejemplo de conexiones 2

Notas (2-B)

- Asegúrese de conectar primero el cable de conexión a masa antes de realizar la conexión del amplificador.
- La alarma sonará únicamente si se utiliza el amplificador incorporado.



Connection diagram 3

- To a metal surface of the car**
First connect the black ground lead, then connect the yellow and red power input leads.
 - To the power antenna control lead or power supply lead of antenna booster amplifier**
Notes
 - It is not necessary to connect this lead if there is no power antenna or antenna booster, or with a manually-operated telescopic antenna.
 - When your car has a built-in FM/AM antenna in the rear/side glass, see "Notes on the control and power supply leads."
 - To AMP REMOTE IN of an optional power amplifier**
This connection is only for amplifiers. Connecting any other system may damage the unit.
 - To the +12 V power terminal which is energized in the accessory position of the ignition key switch**
Notes
 - If there is no accessory position, connect to the +12 V power (battery) terminal which is energized at all times. Be sure to connect the black ground lead to a metal surface of the car first.
 - When your car has a built-in FM/AM antenna in the rear/side glass, see "Notes on the control and power supply leads."
 - To the +12 V power terminal which is energized at all times**
Be sure to connect the black ground lead to a metal surface of the car first.
- Notes on the control and power supply leads**
- The power antenna control lead (blue) supplies +12 V DC when you turn on the tuner.
 - When your car has built-in FM/AM antenna in the rear/side glass, connect the power antenna control lead (blue) or the accessory power input lead (red) to the power terminal of the existing antenna booster. For details, consult your dealer.
 - A power antenna without a relay box cannot be used with this unit.


- Memory hold connection**
- When the yellow power input lead is connected, power will always be supplied to the memory circuit even when the ignition switch is turned off.
- Notes on speaker connection**
- Before connecting the speakers, turn the unit off.
 - Use speakers with an impedance of 4 to 8 ohms, and with adequate power handling capacities to avoid its damage.
 - Do not connect the speaker terminals to the car chassis, or connect the terminals of the right speakers with those of the left speaker.
 - Do not connect the ground lead of this unit to the negative (-) terminal of the speaker.
 - Do not attempt to connect the speakers in parallel.
 - Connect only passive speakers. Connecting active speakers (with built-in amplifiers) to the speaker terminals may damage the unit.
 - To avoid a malfunction, do not use the built-in speaker leads installed in your car if the unit shares a common negative (-) lead for the right and left speakers.
 - Do not connect the unit's speaker leads to each other.
- Note on connection**
- If speaker and amplifier are not connected correctly, "FAILURE" appears in the display. In this case, make sure the speaker and amplifier are connected correctly.

Diagrama de conexión 3

- A una superficie metálica del automóvil**
Conecte primero el cable de conexión a masa negro, y después los cables con rayas naranjas y blancas, amarillo, y rojo de entrada de alimentación.
 - Al cable de control de la antena motorizada o al cable de fuente de alimentación del amplificador de señal de la antena**
Notas
 - Si no se dispone de antena motorizada ni de amplificador de antena, o se utiliza una antena telescópica accionada manualmente, no será necesario conectar este cable.
 - Si el automóvil incorpora una antena de FM/AM en el cristal posterior o lateral, consulte "Notas sobre los cables de control y de fuente de alimentación".
 - A la toma AMP REMOTE IN de un amplificador de potencia opcional**
Esta conexión es sólo para amplificador cadores. La conexión de cualquier otro sistema puede dañar la unidad.
 - Al terminal de alimentación de +12 V que recibe energía en la posición de accesorio del interruptor de la llave de encendido**
Notas
 - Si no hay posición de accesorio, conéctelo al terminal de alimentación (batería) de +12 V que recibe energía sin interrupción.
 - Asegúrese de conectar primero el cable de conexión a masa negro a una superficie metálica del automóvil.
 - Si el automóvil incorpora una antena de FM/AM en el cristal posterior o lateral, consulte "Notas sobre los cables de control y de fuente de alimentación".
 - Al terminal de alimentación de +12 V que recibe energía sin interrupción**
Asegúrese de conectar primero el cable de conexión a masa negro a una superficie metálica del automóvil.
- Notas sobre los cables de control y de fuente de alimentación**
- El cable de control de la antena motorizada (azul) suministrará cc de +12 V cuando conecte la alimentación del sintonizador.
 - Si el automóvil dispone de una antena de FM/AM incorporada en el cristal posterior o lateral, conecte el cable de control de antena motorizada (azul) o el cable de entrada de alimentación auxiliar (rojo) al terminal de alimentación del amplificador de antena existente. Para obtener más información, consulte a su distribuidor.
 - Con esta unidad no es posible utilizar una antena motorizada sin caja de relé.
- Conexión para protección de la memoria**
- Si conecta el cable de entrada de alimentación amarillo, el circuito de la memoria recibirá siempre alimentación, aunque apague el interruptor de encendido.
- Notas sobre la conexión de los altavoces**
- Antes de conectar los altavoces, desconecte la alimentación de la unidad.
 - Utilice altavoces con una impedancia de 4 a 8 Ω con la capacidad de potencia adecuada para evitar que se dañen.
 - No conecte los terminales de altavoz al chasis del automóvil, ni conecte los terminales del altavoz derecho con los del izquierdo.
 - No conecte el cable de conexión a masa de esta unidad al terminal negativo (-) del altavoz.
 - No intente conectar los altavoces en paralelo.
 - Conecte solamente altavoces pasivos. Si conecta altavoces activos (con amplificadores incorporados) a los terminales de altavoz, puede dañar la unidad.
 - Para evitar fallas de funcionamiento, no utilice los cables de altavoz incorporados instalados en el automóvil si la unidad comparte un cable negativo común (-) para los altavoces derecho e izquierdo.
 - No conecte los cables de altavoz de la unidad entre sí.
- Nota sobre la conexión**
- Si el altavoz y el amplificador no están conectados correctamente, aparecerá "Failure" en la pantalla. En tal caso compruebe la conexión de ambos dispositivos.


SECTION 2 DISASSEMBLY

Note: This set can be disassemble according to the following sequence.




Note: Follow the disassembly procedure in the numerical order given.


2-1. SUB PANEL ASSY




2-2. CD MECHANISM BLOCK




2-3. MAIN BOARD




2-4. CHASSIS (T) SUB ASSY





2-5. ROLLER ARM ASSY




2-6. CHASSIS (OP) ASSY




2-7. OPTICAL PICK-UP**2-8. SL MOTOR ASSY (M902)**

2-9. LE MOTOR ASSY (M903)




2-10. SERVO BOARD




SECTION 3 DIAGRAMS


3-1. BLOCK DIAGRAM — CD SECTION —



3-2. BLOCK DIAGRAM — MAIN SECTION —



3-3. BLOCK DIAGRAM — DISPLAY SECTION —



• NOTE FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

**THIS NOTE IS COMMON FOR PRINTED WIRING
BOARDS AND SCHEMATIC DIAGRAMS.**
(In addition to this, the necessary note is
printed in each block.)

For schematic diagrams.

Note:

- All capacitors are in μF unless otherwise noted. (p: pF)
50 WV or less are not indicated except for electrolytics and tantalums.
- All resistors are in Ω and $\frac{1}{4}\text{W}$ or less unless otherwise specified.
- Δ : internal component.
- : panel designation.

Note: The components identified by mark  or dotted line with mark  are critical for safety.
Replace only with part number specified.


-  : B+ Line.
-  : B- Line.
-  : adjustment for repair.
- Voltages and waveforms are dc with respect to ground under no-signal (detuned) conditions.
- CD mechanism section
no mark : CD PLAY
- Main (1/3), (2/3), (3/3) and Key sections
no mark : FM
() : AM
<  > : CD PLAY
*  : Impossible to measure
- Voltages are taken with a VOM (Input impedance 10 MΩ).
Voltage variations may be noted due to normal production tolerances.
- Waveforms are taken with an oscilloscope.
Voltage variations may be noted due to normal production tolerances.
- Circled numbers refer to waveforms.
- Signal path.
 : CD PLAY
 : FM
 : AM
 : AUX

For printed wiring boards.


Note:

- ○ — : parts extracted from the component side.
- — : parts extracted from the conductor side.
- ○ : Through hole.
- ■ : Pattern from the side which enables seeing.
(The other layers' patterns are not indicated.)


Caution:
 Pattern face side: Parts on the pattern face side seen from the pattern face are indicated.
 Parts face side: Parts on the parts face side seen from the parts face are indicated.



3-4. CIRCUIT BOARDS LOCATION




3-5. PRINTED WIRING BOARDS — CD MECHANISM SECTION — • Refer to page 15 for Circuit Boards Location. : Uses unleaded solder.




3-6. SCHEMATIC DIAGRAM — CD MECHANISM SECTION —

- Refer to page 24 for Waveforms.
- Refer to page 24 for IC Block Diagram.
- Refer to page 27 for IC Pin Description of IC1.




3-7. PRINTED WIRING BOARD — MAIN SECTION — • Refer to page 15 for Circuit Boards Location. : Uses unleaded solder.



19





3-9. SCHEMATIC DIAGRAM — MAIN SECTION (2/3) — • Refer to page 26 for IC Block Diagram.



3-10. SCHEMATIC DIAGRAM — MAIN SECTION (3/3) —

• Refer to page 24 for Waveforms.
• Refer to page 29 for IC Pin Description of IC501.






23




• WAVEFORMS

— SERVO Board — (CD PLAY)




— MAIN Board —




• IC BLOCK DIAGRAMS


IC2 BA5966FP-FE2 (SERVO Board)



IC401 BD3806AFS-E2 (MAIN Board (1/3))



IC750 TDA8589BJ/N2/R1 (MAIN Board (2/3))



• IC PIN DESCRIPTIONS

IC1 μ PD63712GC-8EU-A (RF AMP, DIGITAL SERVO, DIGITAL SIGNAL PROCESSOR) (SERVO BOARD)

Pin No.	Pin Name	I/O	Pin Description
1	LD	O	Laser diode ON/OFF control signal output (L: laser OFF, H: laser ON)
2	PD	I	Dimmer monitor input from optical pick-up laser diode.
3	PN	I	Not used. (Fixed at L in this set.)
4	AVDD	—	Analog power supply pin (+3.3 V)
5	DGND	—	Ground pin
6	RFOK	O	RFOK signal output to system control IC.
7	INTQ	O	CD text pack synchronization signal output to system control IC.
8	$\overline{\text{RST}}$	I	CD reset signal input from system control IC.
9	$\overline{\text{A0}}$	I	Command/parameter discrimination signal input from system control IC. (L: command transmission, H: parameter transmission)
10	$\overline{\text{STB}}$	I	Data strobe signal input from system control IC.
11	$\overline{\text{SCK}}$	I	Serial clock signal input from system control IC.
12	SO	O	Serial data signal output to system control IC.
13	SI	I	Serial data signal input from system control IC.
14	DVDD	—	Power supply pin (+3.3 V)
15	DAVDD	—	D/A converter power supply (+) pin (+3.3 V)
16	ROUT	O	Analog audio signal output (R-ch)
17	DAGND	—	Ground pin
18	REGC	—	Capacitor connection pin for SCF regulator.
19	DAGND	—	Ground pin
20	LOUT	O	Analog audio signal output (L-ch)
21	DAVDD	—	D/A converter power supply (+) pin (+3.3 V)
22	XVDD	—	Power supply pin (+3.3 V)
23	$\overline{\text{XTAL}}$	O	Main system clock output (16.9344 MHz)
24	XTAL	I	Main system clock input (16.9344 MHz)
25	XGND	—	Ground pin
26	DVDD	—	Power supply pin (+3.3 V)
27	C1D1/FZD	O	Not used. (Open)
28	C1D2/TZD	O	Not used. (Open)
29	C2D1/RMUTE	O	CD R-ch data zero detection signal output
30	C2D2/LMUTE	O	CD L-ch data zero detection signal output
31	C2D3/SHOCK/SBSY	O	Not used. (Open)
32	LOCK/FR	O	Not used. (Open)
33	WFCK/MIRR	O	Not used. (Open)
34	RFCK/HOLD	O	Not used. (Open)
35	PLCK	O	Not used. (Open)
36	C16M	O	Not used. (Open)
37	DGND	—	Ground pin
38	TX	O	Not used. (Open)
39	EMPH/RAMOVER	O	Not used. (Open)
40	FLAG	O	Not used. (Open)
41	DVDD	—	Power supply pin (+3.3 V)
42	LIMIT	I	Not used. (Fixed at L in this set.)
43	$\overline{\text{XTALEN}}$	I	Oscillation circuit ON/OFF control signal input (L: ON, H: OFF) (Fixed at L in this set.)
44	DGND	—	Ground pin
45	DIN	I	Not used. (Connect to DOUT in this set.)
46	DOUT	O	Not used. (Connect to DIN in this set.)


Pin No.	Pin Name	I/O	Pin Description
47	SCKIN	I	Not used. (Connect to SCKO in this set.)
48	SCKO	O	Not used. (Connect to SCKIN in this set.)
49	LRCKIN	I	Not used. (Connect to LRCK in this set.)
50	LRCK	O	Not used. (Connect to LRCKIN in this set.)
51	DVDD	—	Power supply pin (+3.3 V)
52	FD+	O	Focus servo drive PWM signal output (+)
53	FD-	O	Focus servo drive PWM signal output (-)
54	TD+	O	Tracking servo drive PWM signal output (+)
55	TD-	O	Tracking servo drive PWM signal output (-)
56	SD+	O	Sled servo drive PWM signal output (+)
57	SD-	O	Sled servo drive PWM signal output (-)
58	MD+	O	Spindle servo drive PWM signal output (+)
59	MD-	O	Spindle servo drive PWM signal output (-)
60	DGND	—	Ground pin
61	TESTEN	I	Test setting input (Fixed at L in this set.)
62 to 66	TEST4 to TEST0	I	Test setting input (Fixed at L in this set.)
67	ADGND	—	A/D converter power supply (-) pin
68	EFM	O	EFM signal output
69	ASY	I	EFM comparator reference voltage input
70	ADVDD	—	A/D converter power supply pin (+3.3 V)
71	RFI	I	RF signal input for EFM data growing.
72	EQ2	—	Not used. (Open)
73	EQ1	—	RF amplifier equalizer parts connection pin
74	RF-	I	Not used. (Open)
75	RF2-	I	RF amplifier inversion input
76	AGCO	O	RF signal output after on AGC.
77	AGCI	I	RF AGC signal amplifier input
78	RFO	O	RF signal output before on AGC.
79	ATEST	I	Not used. (Open)
80	C3T	—	Capacitor connection pin for 3T detection.
81	AGND	—	Ground pin
82	A	I	Signal input (A) from optical pick-up detector.
83	C	I	Signal input (C) from optical pick-up detector.
84	B	I	Signal input (B) from optical pick-up detector.
85	D	I	Signal input (D) from optical pick-up detector.
86	F	I	Signal input (F) from optical pick-up detector.
87	E	I	Signal input (E) from optical pick-up detector.
88	VREFIN	I	Reference voltage (+1.65 V) input
89	AVDD	—	Analog power supply pin (+3.3 V)
90	REFOUT	O	Reference voltage (+1.65 V) output
91	REFC	—	Capacitor connection pin for reference voltage output.
92	FE-	I	Focus error signal amplifier inversion input
93	FEO	O	Focus error signal amplifier output
94	ADCIN	I	Not used. (Open)
95	TE-	I	Tracking error signal amplifier inversion input
96	TEO	O	Tracking error signal amplifier before output
97	TE2	O	Tracking error signal amplifier after output
98	TEC	I	Tracking error signal comparator input
99	AGND	—	Ground pin
100	PWMSW	I	Not used. (Fixed at L in this set.)

IC501 MB90488BPF-G-186-AE1 (SYSTEM CONTROL) (MAIN BOARD (3/3))

Pin No.	Pin Name	I/O	Pin Description
1	AREASEL2	I	Destination setting pin
2	AREASEL1	I	Destination setting pin
3	AREASEL0	I	Destination setting pin
4	COL SW	I	Illumination color select signal input
5	BEEP	O	Beep signal output
6	CYRIL SEL	I	Cyril select signal input Not used in this set. (Open)
7	NOSE SW	I	Front panel open/close detect signal input Not used in this set.
8	DIAG	I	Power AMP status signal input
9	VOL ATT	O	Electronic volume attenuate control signal output
10	NCO	O	Not used. (Open)
11	VSS	—	Ground pin
12	TU ATT	O	Tuner mute control signal output
13	NS MASK	O	Noise mask signal output Not used in this set. (Open)
14	ILLUMI SEL1	I	Illumination voltage setting signal input 1
15	ILLUMI SEL2	I	Illumination voltage setting signal input 2
16, 17	NCO	O	Not used. (Open)
18	CD SI	I	CD servo serial data signal input
19	CD SO	O	CD servo serial data signal output
20	CD SCK	O	CD servo serial clock signal output
21, 22	NCO	O	Not used. (Open)
23	VCC5	—	Power supply pin (+3.3 V)
24	EEP SIO	I/O	EEPROM bus serial data input/output
25	EEP CKO	O	EEPROM bus serial clock output
26	AMP STB	O	Power AMP standby signal output
27	LCD CE	O	LCD driver chip enable signal output
28	LCD SO	O	LCD driver serial data signal output
29	LCD CKO	O	LCD driver serial clock signal output
30	RDS ON	O	RDS ON signal output Not used in this set. (Open)
31	RE IN0	I	Rotary encoder signal input 0
32	RE IN1	I	Rotary encoder signal input 1
33	I2C CKO	O	I2C bus serial clock signal output
34	I2C SIO	I/O	I2C bus serial data signal input/output
35	DAVDD	—	A/D converter power supply pin (+3.3 V)
36	AVRH	—	A/D converter external reference power supply pin (+3.3 V)
37	DAVSS	—	Ground pin
38	QUALITY	I	Noise detect signal input Not used in this set.
39	VSM	I	S-meter voltage detect signal input
40	KEY IN1	I	Key signal input 1
41	KEY IN0	I	Key signal input 0
42	VSS	—	Ground pin
43	RC IN0	I	Rotary commander key signal input
44 to 48	NCO	O	Not used. (open)
49	MD0	I	Operation mode setting pin (Connect to VDD.)
50	MD1	I	Operation mode setting pin (Connect to VDD.)
51	MD2	I	Operation mode setting pin (Connect to VSS.)
52	KEY ACK	I	Key acknowledgment detect signal input
53	TU ATT IN	I	Tuner mute zero cross detect signal input
54	BU IN	I	Back-up power supply detect signal input
55	CD INTQ	I	CD servo text pack synchronization signal input

Pin No.	Pin Name	I/O	Pin Description
56	DAVN	I	RDS data block synchronized detect signal input Not used in this set.
57	NCO	O	Not used. (Open)
58	UNISI	I	SONY bus data signal input Not used in this set.
59	UNI SO	O	SONY bus data signal output Not used in this set. (Open)
60	UNI SCK	O	SONY bus clock signal output Not used in this set.
61	611 SEL	I	Mechanism deck select signal input Not used in this set. (Open)
62	WMA	I	WMA select signal input Not used in this set. (Open)
63	NCO	O	Not used. (Open)
64	SIRCS	I	Remote control signal input Not used in this set.
65 to 67	NCO	O	Not used. (Open)
68	FLASH W	I	Memory mode select signal input Not used in this set.
69, 70	NCO	O	Not used. (Open)
71	RC IN1	I	Rotary commander shift key signal input Not used in this set.
72	ACC IN	I	Accessory power supply detect signal input
73	TEST IN	I	Test mode detect signal input
74	TEL ATT	I	Telephone attenuate detect signal input Not used in this set.
75	NCO	O	Not used. (Open)
76	XKEY ON	O	A/D converter power supply control signal output
77	RESET	I	CPU reset signal input
78	NCO	O	Not used. (Open)
79	XOUT	O	Sub-clock output (32.768 kHz)
80	XIN	I	Sub-clock input (32.768 kHz)
81	VSS1	—	Ground pin
82	OSC IN	I	Main-clock input (18.432 MHz)
83	OSC OUT	O	Main-clock output (18.432 MHz)
84	VCC3	—	Power supply pin (+3.3 V)
85	DEMOSEL	I	DEMO select signal input
86	ATT	O	Audio mute control signal output
87	BUS ON	O	Bus on signal output
88	SYS RST	O	System reset signal output
89	CD RFOK	O	Shutter open information signal output to CD mechanism
90	CD RST	O	CD servo reset signal output
91	CD A0	O	CD servo command/parameter signal output
92	CD STB	O	CD servo data strob signal output
93	CD MUTE R	I	CD mechanism zero cross mute detect signal input R
94	CD MUTE L	I	CD mechanism zero cross mute detect signal input L
95	CD INSW	I	CD mechanism disc in switch detect signal input
96	CD SELF SW	I	CD self switch signal input
97	CD LM LO	O	CD mechanism loading motor (+6 V) control signal output
98	CD LM EJ	O	CD mechanism eject motor control signal output
99	CD DSW	I	CD mechanism disc in switch detect signal input
100	CD LIMIT	I	CD mechanism limit switch detect signal input


4-2. FRONT PANEL SECTION



Ref. No.	Part No.	Description	Remark
51	X-2067-579-1	BUTTON ASSY (S)	
52	X-2149-325-1	PANEL SUB ASSY, FRONT	
53	2-631-526-11	PLATE (CD), LIGHT GUIDE	
54	A-1206-099-A	PANEL ASSY, FRONT	
55	X-2102-729-1	KNOB (VOL) (SV) ASSY	
56	2-349-626-01	SPRING (RELEASE)	
57	1-780-199-11	CONDUCTIVE BOARD, CONNECTION	
58	2-634-438-01	ILLUMINATOR (LCD)	


Ref. No.	Part No.	Description	Remark
59	X-2067-569-1	HOLDER (LCD) ASSY	
60	3-251-320-01	EMBLEM (NO. 2.5), SONY	
61	2-631-511-04	PANEL, FRONT BACK	
62	3-040-315-01	COVER (AC OUT)	
63	3-250-543-91	SCREW (+B P-TITE M2)	
LCD901	1-805-920-11	DISPLAY PANEL, LIQUID CRYSTAL	
RE901	1-478-474-12	ENCODER, ROTARY (PUSH SELECT/VOLUME)	

4-3. CD MECHANISM SECTION (1) (MG-611XE-186//C)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	A-1088-624-A	CHASSIS (T) SUB ASSY		105	2-345-767-21	SPRING (KF60), TENSION	
102	A-1083-497-A	SERVO BOARD, COMPLETE		106	3-253-748-11	DAMPER (S)	
103	2-345-865-11	SPRING (DAMPER), COMPRESSION (BLACK)		107	3-352-758-31	SCREW (M1.7X2.5), TOOTHED LOCK	
104	2-345-865-01	SPRING (DAMPER), COMPRESSION (NATURAL)		#4	7-627-552-87	SCREW, PRECISION +P 1.7X2.2	

4-4. CD MECHANISM SECTION (2)
(MG-611XE-186//C)




Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
151	A-1088-612-A	CHASSIS (OP) COMPLETE ASSY		158	3-261-959-21	SPRING (SL), TORSION	
152	3-316-938-91	SCREW (B1.4X5), TAPPING		159	3-253-736-21	SPRING (CHKG), TENSION	
▲ 153	8-820-207-12	OPTICAL PICK-UP (KSS1000E/K1RP)		160	3-253-742-21	WHEEL (SL), WORM	
154	A-1088-615-A	CHASSIS (OP) SUB ASSY (including M901)		M902	A-1088-614-A	MOTOR ASSY, SL (SLED)	
155	A-1088-616-A	ARM SUB ASSY, CHUCKING		SW4	1-786-339-11	SWITCH (M) (LIMIT)	
156	A-1088-613-A	LEVER (SL) SUB ASSY		#5	7-627-850-77	SCREW, PRECISION +P 1.4X1.8	
157	X-2024-784-3	LEVER (SL) ASSY					

4-5. CD MECHANISM SECTION (3) (MG-611XE-186//C)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
201	3-262-755-11	WASHER (1.1-2.5)		208	2-186-696-22	BRACKET (LEM-N)	
202	2-186-699-21	GEAR (RA1)		209	3-345-648-91	SCREW (M1.4), TOOTHED LOCK	
203	A-1088-618-A	ARM ASSY, ROLLER		210	A-1088-623-A	GEAR (LE) ASSY	
204	3-259-455-21	SPRING (RAL)		211	2-186-697-21	BEARING (LEB-N)	
205	3-253-713-21	SPRING (RAR)		M903	A-1088-622-A	MOTOR ASSY, LE (LOADING)	
206	3-259-469-21	SPRING (LE), LEAF		#4	7-627-552-87	SCREW, PRECISION +P 1.7X2.2	
207	2-134-636-51	SCREW (M1.7X2.5)					

4-6. CD MECHANISM SECTION (4)
(MG-611XE-186//C)



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251	2-186-700-21	GEAR (CHK1)		254	2-590-545-22	GEAR (LE2-M)	
252	3-259-470-24	GEAR (LE1)		255	A-1088-620-A	CHASSIS (M) BLOCK ASSY	
253	3-253-755-23	LEVER (D)		256	3-262-755-11	WASHER (1.1-2.5)	

SECTION 5 ELECTRICAL PARTS LIST

JACK

KEY

NOTE:

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX and -X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL: Metal-film resistor.
METAL OXIDE: Metal oxide-film resistor.
F: nonflammable
- Items marked “*” are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u : μ , for example:
uA.. : μ A.. uPA.. : μ PA..
uPB.. : μ PB.. uPC.. : μ PC.. uPD.. : μ PD..
- CAPACITORS
uF : μ F
- COILS
uH : μ H

The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

When indicating parts by reference number, please include the board.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
		JACK BOARD				< SWITCH >	

		< JACK >					
J901	1-819-732-11	JACK (DIA. 3.5) (AUX)		LSW901	1-786-806-12	SWITCH, TACTILE (WITH LED) (Δ)	
*****				LSW902	1-786-806-12	SWITCH, TACTILE (WITH LED) (OFF)	
				LSW903	1-786-806-12	SWITCH, TACTILE (WITH LED) (SOURCE)	
				LSW908	1-786-806-12	SWITCH, TACTILE (WITH LED) (EQ3)	
				LSW909	1-786-806-12	SWITCH, TACTILE (WITH LED)	(▶▶▶▶ SEEK +)
		KEY BOARD		LSW910	1-786-806-12	SWITCH, TACTILE (WITH LED)	(◀◀◀◀ SEEK -)

		< CAPACITOR >		LSW911	1-786-806-12	SWITCH, TACTILE (WITH LED) (BTM)	
C921	1-163-031-11	CERAMIC CHIP 0.01uF	50V	LSW912	1-786-806-12	SWITCH, TACTILE (WITH LED) (MODE)	
C922	1-163-031-11	CERAMIC CHIP 0.01uF	50V	LSW913	1-786-806-12	SWITCH, TACTILE (WITH LED) (1)	
C981	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V	LSW914	1-786-806-12	SWITCH, TACTILE (WITH LED) (2)	
C983	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V				
C984	1-107-826-11	CERAMIC CHIP 0.1uF	10% 16V	LSW915	1-786-806-12	SWITCH, TACTILE (WITH LED) (3/REP)	
				LSW916	1-786-806-12	SWITCH, TACTILE (WITH LED) (4/SHUF)	
C985	1-131-664-11	CERAMIC CHIP 0.15uF	10% 10V	LSW917	1-786-806-12	SWITCH, TACTILE (WITH LED) (5)	
C986	1-127-715-11	CERAMIC CHIP 0.22uF	10% 16V	LSW918	1-786-806-12	SWITCH, TACTILE (WITH LED) (6)	
				LSW919	1-786-806-12	SWITCH, TACTILE (WITH LED) (SENS)	
		< CONNECTOR >		LSW920	1-786-806-12	SWITCH, TACTILE (WITH LED) (DSPL/DIM)	
CN901	1-819-758-12	PLUG, CONNECTOR 15P				< TRANSISTOR >	
		< DIODE >		Q931	8-729-027-44	TRANSISTOR DTC114TKA-T146	
D901	6-500-886-01	DIODE RSA6.1ENTR		Q932	8-729-027-58	TRANSISTOR DTC143ZKA-T146	
D903	6-501-180-01	DIODE UDZW-TE17-18B				< RESISTOR >	
D981	6-501-167-01	DIODE UDZW-TE17-5.1B					
D982	6-501-193-01	DIODE 1SS355WTE-17		R901	1-216-819-11	METAL CHIP 680 5% 1/10W	
				R902	1-216-819-11	METAL CHIP 680 5% 1/10W	
		< JUMPER RESISTOR >		R903	1-216-819-11	METAL CHIP 680 5% 1/10W	
FB901	1-216-864-11	SHORT CHIP 0		R904	1-216-821-11	METAL CHIP 1K 5% 1/10W	
FB902	1-216-864-11	SHORT CHIP 0		R905	1-216-823-11	METAL CHIP 1.5K 5% 1/10W	
FB903	1-216-295-11	SHORT CHIP 0					
				R906	1-216-819-11	METAL CHIP 680 5% 1/10W	
		< IC >		R907	1-216-819-11	METAL CHIP 680 5% 1/10W	
IC901	6-707-063-01	IC LC75826WH-US-E		R908	1-216-819-11	METAL CHIP 680 5% 1/10W	
				R909	1-216-821-11	METAL CHIP 1K 5% 1/10W	
				R910	1-216-823-11	METAL CHIP 1.5K 5% 1/10W	
		< DIODE >					
LED932	6-501-339-01	LED NESW505CT-AST (LCD BACK LIGHT)		R911	1-216-823-11	METAL CHIP 1.5K 5% 1/10W	
				R912	1-216-825-11	METAL CHIP 2.2K 5% 1/10W	
		< RESISTOR >		R913	1-216-827-11	METAL CHIP 3.3K 5% 1/10W	
LED951	1-216-810-11	METAL CHIP 120 5% 1/10W		R914	1-216-829-11	METAL CHIP 4.7K 5% 1/10W	
				R915	1-218-867-11	METAL CHIP 6.8K 0.5% 1/10W	
				R916	1-216-833-11	METAL CHIP 10K 5% 1/10W	
				R917	1-216-835-11	METAL CHIP 15K 5% 1/10W	
				R918	1-216-837-11	METAL CHIP 22K 5% 1/10W	
				R921	1-216-025-11	RES-CHIP 100 5% 1/10W	

CDX-GT06/CXS-GT06HP

KEY MAIN

Ref. No.	Part No.	Description	Remark		
R922	1-216-025-11	RES-CHIP	100	5%	1/10W
R931	1-216-812-11	METAL CHIP	180	5%	1/10W
R932	1-216-812-11	METAL CHIP	180	5%	1/10W
R933	1-216-812-11	METAL CHIP	180	5%	1/10W
R934	1-216-822-11	METAL CHIP	1.2K	5%	1/10W
R941	1-216-810-11	METAL CHIP	120	5%	1/10W
R942	1-216-810-11	METAL CHIP	120	5%	1/10W
R943	1-216-810-11	METAL CHIP	120	5%	1/10W
R944	1-216-811-11	METAL CHIP	150	5%	1/10W
R945	1-216-810-11	METAL CHIP	120	5%	1/10W
R946	1-216-807-11	METAL CHIP	68	5%	1/10W
R947	1-216-807-11	METAL CHIP	68	5%	1/10W
R948	1-216-811-11	METAL CHIP	150	5%	1/10W
R949	1-216-810-11	METAL CHIP	120	5%	1/10W
R950	1-216-807-11	METAL CHIP	68	5%	1/10W
R951	1-216-807-11	METAL CHIP	68	5%	1/10W
R952	1-216-810-11	METAL CHIP	120	5%	1/10W
R953	1-216-811-11	METAL CHIP	150	5%	1/10W
R954	1-216-810-11	METAL CHIP	120	5%	1/10W
R955	1-216-811-11	METAL CHIP	150	5%	1/10W
R956	1-216-810-11	METAL CHIP	120	5%	1/10W
R957	1-216-811-11	METAL CHIP	150	5%	1/10W
R958	1-216-810-11	METAL CHIP	120	5%	1/10W
R974	1-216-864-11	SHORT CHIP	0		
R976	1-216-864-11	SHORT CHIP	0		
R977	1-216-809-11	METAL CHIP	100	5%	1/10W
R978	1-216-809-11	METAL CHIP	100	5%	1/10W
R979	1-216-809-11	METAL CHIP	100	5%	1/10W
R981	1-216-811-11	METAL CHIP	150	5%	1/10W
R982	1-216-811-11	METAL CHIP	150	5%	1/10W
R984	1-216-821-11	METAL CHIP	1K	5%	1/10W
R985	1-216-821-11	METAL CHIP	1K	5%	1/10W
R986	1-216-821-11	METAL CHIP	1K	5%	1/10W
R987	1-216-857-11	METAL CHIP	1M	5%	1/10W
R991	1-216-864-11	SHORT CHIP	0		

A-1206-054-A	MAIN BOARD, COMPLETE				

7-621-284-40	SCREW +P 2.6X10				
7-685-134-19	SCREW +P 2.6X8 TYPE2 NON-SLIT				
7-685-793-09	SCREW +PTT 2.6X8 (S)				
7-685-795-09	SCREW +PTT 2.6X12 (S)				
	< CAPACITOR >				
C4	1-126-947-11	ELECT	47uF	20%	35V
C5	1-126-947-11	ELECT	47uF	20%	35V
C6	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C7	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C12	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C13	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C301	1-128-551-11	ELECT	22uF	20%	63V
C302	1-104-665-11	ELECT	100uF	20%	25V
C303	1-128-551-11	ELECT	22uF	20%	63V
C305	1-104-665-11	ELECT	100uF	20%	25V
C306	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C307	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C308	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C343	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V

Ref. No.	Part No.	Description	Remark		
C401	1-126-964-11	ELECT	10uF	20%	50V
C404	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V
C405	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V
C406	1-126-960-11	ELECT	1uF	20%	50V
C407	1-126-960-11	ELECT	1uF	20%	50V
C410	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C411	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
C412	1-126-934-11	ELECT	220uF	20%	16V
C413	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C431	1-126-964-11	ELECT	10uF	20%	50V
C432	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C435	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C441	1-126-964-11	ELECT	10uF	20%	50V
C442	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C445	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C451	1-126-964-11	ELECT	10uF	20%	50V
C452	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C455	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C461	1-126-964-11	ELECT	10uF	20%	50V
C462	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C465	1-165-908-11	CERAMIC CHIP	1uF	10%	10V
C471	1-126-964-11	ELECT	10uF	20%	50V
C474	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C479	1-126-947-11	ELECT	47uF	20%	35V
C481	1-126-964-11	ELECT	10uF	20%	50V
C484	1-163-251-11	CERAMIC CHIP	100PF	5%	50V
C501	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C502	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C503	1-104-665-11	ELECT	100uF	20%	25V
C504	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C507	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C508	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C509	1-162-966-11	CERAMIC CHIP	0.0022uF	10%	50V
C510	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C511	1-104-665-11	ELECT	100uF	20%	25V
C512	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C513	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C514	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C516	1-216-864-11	SHORT CHIP	0		
C519	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C601	1-131-868-81	ELECT	3300uF	20%	16V
C602	1-165-319-11	CERAMIC CHIP	0.1uF		50V
C617	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
C618	1-163-009-11	CERAMIC CHIP	0.001uF	10%	50V
C622	1-126-916-11	ELECT	1000uF	20%	6.3V
C623	1-126-916-11	ELECT	1000uF	20%	6.3V
C631	1-126-960-11	ELECT	1uF	20%	50V
C750	1-115-340-11	CERAMIC CHIP	0.22uF	10%	25V
C751	1-115-340-11	CERAMIC CHIP	0.22uF	10%	25V
C753	1-128-551-11	ELECT	22uF	20%	63V
C754	1-126-961-11	ELECT	2.2uF	20%	50V
C755	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C756	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V
C758	1-126-964-11	ELECT	10uF	20%	50V
C763	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V
C764	1-115-340-11	CERAMIC CHIP	0.22uF	10%	25V
C765	1-115-340-11	CERAMIC CHIP	0.22uF	10%	25V
C769	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V

Ref. No.	Part No.	Description	Remark		Ref. No.	Part No.	Description	Remark	
C770	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V	FB605	1-216-864-11	SHORT CHIP	0
C771	1-127-715-11	CERAMIC CHIP	0.22uF	10%	16V	FB606	1-216-864-11	SHORT CHIP	0
C774	1-115-340-11	CERAMIC CHIP	0.22uF	10%	25V			< FUSE >	
C775	1-115-340-11	CERAMIC CHIP	0.22uF	10%	25V				
C776	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	FU601	1-532-877-11	FUSE (BLADE TYPE) (AUTO FUSE) 10A	
C901	1-109-982-11	CERAMIC CHIP	1uF	10%	10V			< IC >	
C902	1-109-982-11	CERAMIC CHIP	1uF	10%	10V				
C903	1-126-961-11	ELECT	2.2uF	20%	50V	IC401	6-708-880-01	IC BD3806AFS-E2	
C905	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	IC501	6-806-757-01	IC MB90488BPF-G-186-AE1	
C917	1-163-017-00	CERAMIC CHIP	0.0047uF	10%	50V	IC602	8-759-659-13	IC PST3428UL	
C918	1-163-017-00	CERAMIC CHIP	0.0047uF	10%	50V	IC750	6-705-363-02	IC TDA8589BJ/N2/R1	
		< CONNECTOR >				IC901	8-759-681-42	IC NJM12902V(Te2)	
CN601	1-774-701-21	PIN, CONNECTOR 16P						< JACK >	
CN701	1-819-773-13	SOCKET, CONNECTOR 15P				J1	1-815-185-13	JACK (ANTENNA)	
CNP301	1-817-536-11	CONNECTOR, BOARD TO BOARD 28P				J330	1-774-698-11	JACK, PIN 2P (AUDIO OUT REAR L/R)	
		< DIODE >						< JUMPER RESISTOR >	
D1	6-501-168-01	DIODE UDZW-TE17-5.6B				JC1	1-216-864-11	SHORT CHIP	0
D479	6-501-193-01	DIODE 1SS355WTE-17				JC501	1-216-864-11	SHORT CHIP	0
D503	6-501-193-01	DIODE 1SS355WTE-17				JC504	1-216-864-11	SHORT CHIP	0
D580	6-501-171-01	DIODE UDZW-TE17-7.5B				JC534	1-216-864-11	SHORT CHIP	0
D581	6-501-180-01	DIODE UDZW-TE17-18B				JC536	1-216-864-11	SHORT CHIP	0
D601	8-719-049-38	DIODE 1N5404TU				JC681	1-216-864-11	SHORT CHIP	0
D609	6-501-170-01	DIODE UDZW-TE17-6.8B				JC753	1-216-296-11	SHORT CHIP	0
D617	6-501-180-01	DIODE UDZW-TE17-18B				JC754	1-216-296-11	SHORT CHIP	0
D704	1-216-295-11	SHORT CHIP	0			JC755	1-216-296-11	SHORT CHIP	0
D719	6-501-180-01	DIODE UDZW-TE17-18B				JC756	1-216-864-11	SHORT CHIP	0
D751	6-500-522-01	DIODE 10EDB40-TA1B2				JC795	1-216-864-11	SHORT CHIP	0
D752	6-500-522-01	DIODE 10EDB40-TA1B2						< COIL >	
D753	6-500-522-01	DIODE 10EDB40-TA1B2				L1	1-469-844-11	INDUCTOR	2.2uH
D754	6-500-522-01	DIODE 10EDB40-TA1B2				L301	1-216-295-11	SHORT CHIP	0
D755	6-500-522-01	DIODE 10EDB40-TA1B2				L501	1-216-295-11	SHORT CHIP	0
D756	6-500-522-01	DIODE 10EDB40-TA1B2				L601	1-456-617-11	COIL, CHOKE	
D757	6-500-522-01	DIODE 10EDB40-TA1B2						< TRANSISTOR >	
D758	6-500-522-01	DIODE 10EDB40-TA1B2				Q1	6-551-431-01	TRANSISTOR	2SC6027T100-QR
D759	6-500-522-01	DIODE 10EDB40-TA1B2				Q431	8-729-027-44	TRANSISTOR	DTC114TKA-T146
D760	6-500-522-01	DIODE 10EDB40-TA1B2				Q441	8-729-027-44	TRANSISTOR	DTC114TKA-T146
D761	6-500-522-01	DIODE 10EDB40-TA1B2				Q451	8-729-027-44	TRANSISTOR	DTC114TKA-T146
D762	6-500-522-01	DIODE 10EDB40-TA1B2				Q461	8-729-027-44	TRANSISTOR	DTC114TKA-T146
D903	6-501-170-01	DIODE UDZW-TE17-6.8B							
		< FERRITE BEAD >				Q471	6-551-392-01	TRANSISTOR	RT6N140C-TP-1
FB1	1-500-245-11	INDUCTOR, FERRITE BEAD				Q478	1-801-806-11	TRANSISTOR	DTC144EKA
FB301	1-216-864-11	SHORT CHIP	0			Q479	8-729-027-23	TRANSISTOR	DTA114EKA-T146
FB302	1-216-864-11	SHORT CHIP	0			Q481	6-551-392-01	TRANSISTOR	RT6N140C-TP-1
FB303	1-216-864-11	SHORT CHIP	0			Q580	8-729-027-43	TRANSISTOR	DTC114EKA-T146
FB304	1-216-295-11	SHORT CHIP	0						
FB305	1-216-295-11	SHORT CHIP	0			Q581	1-801-806-11	TRANSISTOR	DTC144EKA
FB306	1-216-295-11	SHORT CHIP	0			Q582	8-729-120-28	TRANSISTOR	2SC1623-L5L6
FB307	1-216-864-11	SHORT CHIP	0			Q631	8-729-120-28	TRANSISTOR	2SC1623-L5L6
FB310	1-216-864-11	SHORT CHIP	0			Q664	8-729-027-23	TRANSISTOR	DTA114EKA-T146
FB311	1-216-864-11	SHORT CHIP	0					< RESISTOR >	
FB410	1-216-864-11	SHORT CHIP	0			R1	1-216-821-11	METAL CHIP	1K 5% 1/10W
FB411	1-216-864-11	SHORT CHIP	0			R2	1-414-595-11	INDUCTOR, FERRITE BEAD	
FB501	1-216-295-11	SHORT CHIP	0			R3	1-414-595-11	INDUCTOR, FERRITE BEAD	
FB603	1-216-295-11	SHORT CHIP	0			R4	1-216-839-11	METAL CHIP	33K 5% 1/10W
FB604	1-500-245-11	INDUCTOR, FERRITE BEAD				R5	1-216-843-11	METAL CHIP	68K 5% 1/10W

CDX-GT06/CXS-GT06HP

MAIN

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
R12	1-414-595-11	INDUCTOR, FERRITE BEAD				R538	1-216-845-11	METAL CHIP	100K	5%	1/10W
R13	1-414-595-11	INDUCTOR, FERRITE BEAD				R539	1-216-864-11	SHORT CHIP	0		
R301	1-216-821-11	METAL CHIP	1K	5%	1/10W	R540	1-216-845-11	METAL CHIP	100K	5%	1/10W
R302	1-216-821-11	METAL CHIP	1K	5%	1/10W	R541	1-216-845-11	METAL CHIP	100K	5%	1/10W
R401	1-216-797-11	METAL CHIP	10	5%	1/10W	R543	1-216-821-11	METAL CHIP	1K	5%	1/10W
R405	1-218-881-11	METAL CHIP	27K	0.5%	1/10W	R544	1-216-821-11	METAL CHIP	1K	5%	1/10W
R406	1-216-809-11	METAL CHIP	100	5%	1/10W	R550	1-216-845-11	METAL CHIP	100K	5%	1/10W
R407	1-216-809-11	METAL CHIP	100	5%	1/10W	R551	1-216-845-11	METAL CHIP	100K	5%	1/10W
R408	1-216-809-11	METAL CHIP	100	5%	1/10W	R556	1-216-833-11	METAL CHIP	10K	5%	1/10W
R409	1-216-809-11	METAL CHIP	100	5%	1/10W	R557	1-216-809-11	METAL CHIP	100	5%	1/10W
R410	1-216-809-11	METAL CHIP	100	5%	1/10W	R558	1-216-821-11	METAL CHIP	1K	5%	1/10W
R411	1-216-809-11	METAL CHIP	100	5%	1/10W	R559	1-216-845-11	METAL CHIP	100K	5%	1/10W
R431	1-216-821-11	METAL CHIP	1K	5%	1/10W	R560	1-216-845-11	METAL CHIP	100K	5%	1/10W
R432	1-216-833-11	METAL CHIP	10K	5%	1/10W	R561	1-216-845-11	METAL CHIP	100K	5%	1/10W
R441	1-216-821-11	METAL CHIP	1K	5%	1/10W	R563	1-216-845-11	METAL CHIP	100K	5%	1/10W
R442	1-216-833-11	METAL CHIP	10K	5%	1/10W	R565	1-216-845-11	METAL CHIP	100K	5%	1/10W
R451	1-216-821-11	METAL CHIP	1K	5%	1/10W	R566	1-216-845-11	METAL CHIP	100K	5%	1/10W
R452	1-216-833-11	METAL CHIP	10K	5%	1/10W	R567	1-216-845-11	METAL CHIP	100K	5%	1/10W
R461	1-216-821-11	METAL CHIP	1K	5%	1/10W	R568	1-216-821-11	METAL CHIP	1K	5%	1/10W
R462	1-216-833-11	METAL CHIP	10K	5%	1/10W	R570	1-216-817-11	METAL CHIP	470	5%	1/10W
R471	1-216-809-11	METAL CHIP	100	5%	1/10W	R571	1-216-845-11	METAL CHIP	100K	5%	1/10W
R472	1-216-833-11	METAL CHIP	10K	5%	1/10W	R572	1-216-809-11	METAL CHIP	100	5%	1/10W
R479	1-216-805-11	METAL CHIP	47	5%	1/10W	R575	1-216-845-11	METAL CHIP	100K	5%	1/10W
R481	1-216-809-11	METAL CHIP	100	5%	1/10W	R577	1-216-845-11	METAL CHIP	100K	5%	1/10W
R482	1-216-833-11	METAL CHIP	10K	5%	1/10W	R582	1-216-821-11	METAL CHIP	1K	5%	1/10W
R502	1-216-821-11	METAL CHIP	1K	5%	1/10W	R583	1-216-821-11	METAL CHIP	1K	5%	1/10W
R503	1-216-821-11	METAL CHIP	1K	5%	1/10W	R584	1-216-841-11	METAL CHIP	47K	5%	1/10W
R504	1-218-871-11	METAL CHIP	10K	0.5%	1/10W	R585	1-216-849-11	METAL CHIP	220K	5%	1/10W
R505	1-218-871-11	METAL CHIP	10K	0.5%	1/10W	R601	1-216-845-11	METAL CHIP	100K	5%	1/10W
R507	1-216-845-11	METAL CHIP	100K	5%	1/10W	R609	1-216-821-11	METAL CHIP	1K	5%	1/10W
R508	1-216-864-11	SHORT CHIP	0			R631	1-249-425-11	CARBON	4.7K	5%	1/4W
R509	1-216-812-11	METAL CHIP	180	5%	1/10W	R632	1-216-841-11	METAL CHIP	47K	5%	1/10W
R510	1-216-821-11	METAL CHIP	1K	5%	1/10W	R633	1-216-841-11	METAL CHIP	47K	5%	1/10W
R511	1-216-821-11	METAL CHIP	1K	5%	1/10W	R634	1-216-829-11	METAL CHIP	4.7K	5%	1/10W
R512	1-216-821-11	METAL CHIP	1K	5%	1/10W	R636	1-216-845-11	METAL CHIP	100K	5%	1/10W
R513	1-216-845-11	METAL CHIP	100K	5%	1/10W	R661	1-216-821-11	METAL CHIP	1K	5%	1/10W
R514	1-216-845-11	METAL CHIP	100K	5%	1/10W	R662	1-216-845-11	METAL CHIP	100K	5%	1/10W
R515	1-247-807-31	CARBON	100	5%	1/4W	R663	1-216-821-11	METAL CHIP	1K	5%	1/10W
R516	1-247-807-31	CARBON	100	5%	1/4W	R664	1-216-845-11	METAL CHIP	100K	5%	1/10W
R517	1-216-841-11	METAL CHIP	47K	5%	1/10W	R671	1-216-809-11	METAL CHIP	100	5%	1/10W
R518	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	R672	1-216-809-11	METAL CHIP	100	5%	1/10W
R519	1-216-845-11	METAL CHIP	100K	5%	1/10W	R673	1-216-833-11	METAL CHIP	10K	5%	1/10W
R521	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	R674	1-216-845-11	METAL CHIP	100K	5%	1/10W
R522	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	R675	1-216-821-11	METAL CHIP	1K	5%	1/10W
R523	1-216-821-11	METAL CHIP	1K	5%	1/10W	R676	1-216-821-11	METAL CHIP	1K	5%	1/10W
R524	1-216-821-11	METAL CHIP	1K	5%	1/10W	R677	1-216-864-11	SHORT CHIP	0		
R525	1-216-821-11	METAL CHIP	1K	5%	1/10W	R680	1-216-821-11	METAL CHIP	1K	5%	1/10W
R526	1-216-809-11	METAL CHIP	100	5%	1/10W	R681	1-216-821-11	METAL CHIP	1K	5%	1/10W
R527	1-216-821-11	METAL CHIP	1K	5%	1/10W	R752	1-216-811-11	METAL CHIP	150	5%	1/10W
R528	1-216-845-11	METAL CHIP	100K	5%	1/10W	R756	1-216-841-11	METAL CHIP	47K	5%	1/10W
R529	1-216-821-11	METAL CHIP	1K	5%	1/10W	R757	1-216-864-11	SHORT CHIP	0		
R530	1-216-845-11	METAL CHIP	100K	5%	1/10W	R901	1-216-817-11	METAL CHIP	470	5%	1/10W
R531	1-216-845-11	METAL CHIP	100K	5%	1/10W	R902	1-216-817-11	METAL CHIP	470	5%	1/10W
R532	1-216-845-11	METAL CHIP	100K	5%	1/10W	R903	1-216-834-11	METAL CHIP	12K	5%	1/10W
R533	1-216-845-11	METAL CHIP	100K	5%	1/10W	R904	1-216-834-11	METAL CHIP	12K	5%	1/10W
R534	1-216-833-11	METAL CHIP	10K	5%	1/10W	R905	1-216-841-11	METAL CHIP	47K	5%	1/10W
R535	1-216-845-11	METAL CHIP	100K	5%	1/10W	R906	1-216-841-11	METAL CHIP	47K	5%	1/10W
R536	1-216-845-11	METAL CHIP	100K	5%	1/10W	R907	1-216-845-11	METAL CHIP	100K	5%	1/10W

MAIN

SENSOR

SERVO

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark										
R910	1-216-789-11	METAL CHIP	2.2	5%	1/10W	C73	1-162-962-11	CERAMIC CHIP	470PF	10%	50V								
R911	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C74	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V								
R912	1-216-864-11	SHORT CHIP	0			C75	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V								
R913	1-216-864-11	SHORT CHIP	0			C76	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V								
R914	1-216-825-11	METAL CHIP	2.2K	5%	1/10W	C77	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V								
< SWITCH >						C78	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V								
S702	1-786-826-11	SWITCH, TACTILE (RESET)				C79	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V								
< TUNER UNIT >						< CONNECTOR >													
TU1	A-3220-961-B	TUNER UNIT (TUX-032)				CN1	1-817-275-21	CONNECTOR, BOARD TO BOARD 28P											
< VIBRATOR >						CN2	1-815-016-61	CONNECTOR, FFC/FPC (ZIF) 16P											
X501	1-813-524-21	VIBRATOR, CERAMIC (18.432MHz)				< FERRITE BEAD >													
X502	1-813-202-11	VIBRATOR, CRYSTAL (32.768kHz)	*****			FB1	1-216-864-11	SHORT CHIP	0										
*****						FB2	1-414-760-21	FERRITE, EMI (SMD) (1608)											
						FB3	1-414-760-21	FERRITE, EMI (SMD) (1608)											
						< IC >													
SENSOR BOARD						IC1	6-703-699-01	IC uPD63712GC-8EU-A											
*****						IC2	6-705-002-01	IC BA5966FP-FE2											
< SWITCH >						< FERRITE BEAD >													
SW2	1-529-566-61	SWITCH, PUSH (1 KEY) (SELF)				JR40	1-414-760-21	FERRITE, EMI (SMD) (1608)											
SW3	1-529-566-61	SWITCH, PUSH (1 KEY) (DISC IN)	*****			JR41	1-414-760-21	FERRITE, EMI (SMD) (1608)											
*****						JR90	1-414-760-21	FERRITE, EMI (SMD) (1608)											
A-1083-497-A	SERVO BOARD, COMPLETE					JR91	1-414-760-21	FERRITE, EMI (SMD) (1608)											
*****						< TRANSISTOR >													
< CAPACITOR >						Q1	8-729-904-87	TRANSISTOR	2SB1197K-T-146-R										
C1	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	< RESISTOR >													
C2	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R1	1-216-841-11	METAL CHIP	47K	5%	1/10W								
C5	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R2	1-216-809-11	METAL CHIP	100	5%	1/10W								
C6	1-100-381-11	ELECT CHIP	10uF	20%	16V	R3	1-216-809-11	METAL CHIP	100	5%	1/10W								
C7	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R4	1-216-809-11	METAL CHIP	100	5%	1/10W								
C11	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R5	1-216-809-11	METAL CHIP	100	5%	1/10W								
C13	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R6	1-216-833-11	METAL CHIP	10K	5%	1/10W								
C17	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R7	1-216-840-11	METAL CHIP	39K	5%	1/10W								
C18	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R8	1-414-760-21	FERRITE, EMI (SMD) (1608)											
C19	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R9	1-216-822-11	METAL CHIP	1.2K	5%	1/10W								
C20	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R10	1-414-760-21	FERRITE, EMI (SMD) (1608)											
C21	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R11	1-216-833-11	METAL CHIP	10K	5%	1/10W								
C23	1-162-923-11	CERAMIC CHIP	47PF	5%	50V	R12	1-216-809-11	METAL CHIP	100	5%	1/10W								
C25	1-162-908-11	CERAMIC CHIP	3PF	0.25PF	50V	R13	1-216-833-11	METAL CHIP	10K	5%	1/10W								
C26	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R14	1-216-797-11	METAL CHIP	10	5%	1/10W								
C27	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R15	1-216-797-11	METAL CHIP	10	5%	1/10W								
C28	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R41	1-216-821-11	METAL CHIP	1K	5%	1/10W								
C29	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R42	1-216-821-11	METAL CHIP	1K	5%	1/10W								
C30	1-162-921-11	CERAMIC CHIP	33PF	5%	50V	R44	1-414-760-21	FERRITE, EMI (SMD) (1608)											
C31	1-162-925-11	CERAMIC CHIP	68PF	5%	50V	R45	1-414-760-21	FERRITE, EMI (SMD) (1608)											
C32	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R70	1-216-842-11	METAL CHIP	56K	5%	1/10W								
C34	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R71	1-216-833-11	METAL CHIP	10K	5%	1/10W								
C35	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R72	1-216-842-11	METAL CHIP	56K	5%	1/10W								
C36	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V	R73	1-216-833-11	METAL CHIP	10K	5%	1/10W								
C37	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	R74	1-216-837-11	METAL CHIP	22K	5%	1/10W								
C38	1-104-609-11	ELECT CHIP	100uF	20%	4V	R75	1-216-833-11	METAL CHIP	10K	5%	1/10W								
C39	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	R76	1-216-837-11	METAL CHIP	22K	5%	1/10W								
C70	1-162-965-11	CERAMIC CHIP	0.0015uF	10%	50V														
C71	1-162-965-11	CERAMIC CHIP	0.0015uF	10%	50V														
C72	1-162-962-11	CERAMIC CHIP	470PF	10%	50V														

CDX-GT06/CXS-GT06HP

SERVO

Ref. No.	Part No.	Description	Remark		
R77	1-216-833-11	METAL CHIP	10K	5%	1/10W
R78	1-216-833-11	METAL CHIP	10K	5%	1/10W
R79	1-216-833-11	METAL CHIP	10K	5%	1/10W
R80	1-216-833-11	METAL CHIP	10K	5%	1/10W
R81	1-216-833-11	METAL CHIP	10K	5%	1/10W
R82	1-216-837-11	METAL CHIP	22K	5%	1/10W
R83	1-216-833-11	METAL CHIP	10K	5%	1/10W
R84	1-216-837-11	METAL CHIP	22K	5%	1/10W
R85	1-216-833-11	METAL CHIP	10K	5%	1/10W
< SWITCH >					
SW1	1-529-565-61	SWITCH, PUSH (1 KEY) (DOWN)			
< VIBRATOR >					
X1	1-795-562-21	VIBRATOR, CERAMIC (16.9344MHz)			

MISCELLANEOUS					



57	1-780-199-11	CONDUCTIVE BOARD, CONNECTION			
▲ 153	8-820-207-12	OPTICAL PICK-UP (KSS1000E/K1RP)			
154	A-1088-615-A	CHASSIS (OP) SUB ASSY (including M901)			
LCD901	1-805-920-11	DISPLAY PANEL, LIQUID CRYSTAL			
M902	A-1088-614-A	MOTOR ASSY, SL (SLED)			
M903	A-1088-622-A	MOTOR ASSY, LE (LOADING)			
RE901	1-478-474-12	ENCODER, ROTARY (PUSH SELECT/VOLUME)			
SW4	1-786-339-11	SWITCH (M) (LIMIT)			

ACCESSORIES					

1-826-514-11	SPEAKER (6X9 in.)				
1-826-515-11	SPEAKER (6 1/2 in.)				
2-886-097-11	MANUAL, INSTRUCTION (ENGLISH,SPANISH)				
	(CDX-GT06)				
2-886-098-11	MANUAL, INSTRUCTION, INSTALL (ENGLISH,SPANISH) (CXS-GT06HP)				

Ref. No.	Part No.	Description	Remark
PARTS FOR INSTALLATION AND CONNECTIONS			

301	X-3382-647-1	FRAME ASSY, FITTING	
302	2-187-743-02	COLLAR	
303	3-246-011-01	KEY (FRAME)	
304	3-259-776-01	SCREW (+K 5X8 TP)	
305	1-776-206-21	CORD (WITH CONNECTOR) (POWER)	
306	2-886-394-01	TEMPLATE (for 6X9 in.)	
307	2-886-389-01	TEMPLATE (for 6 1/2 in.)	
308	2-886-393-01	GRILLE (for 6X9 in.)	
309	2-886-388-01	GRILLE (for 6 1/2 in.)	
310	1-824-847-11	CORD, SPEAKER CONNECTION (0.3m)	
311	3-240-189-11	SCREW, SPECIAL	
312	2-585-058-01	NUT, SPEED	



MEMO

REVISION HISTORY

Clicking the version allows you to jump to the revised page.

Also, clicking the version at the upper on the revised page allows you to jump to the next revised page.

[illegible]